





802.11ax (80MHz) 6625MHz Chain C NSS-4

802.11ax (80MHz) 6625MHz Chain D NSS-4





802.11ax (80MHz) 6705MHz Chain A NSS-4

802.11ax (80MHz) 6705MHz Chain B NSS-4





802.11ax (80MHz) 6705MHz Chain C NSS-4

802.11ax (80MHz) 6705MHz Chain D NSS-4





802.11ax (80MHz) 6785MHz Chain A NSS-4

802.11ax (80MHz) 6785MHz Chain B NSS-4





802.11ax (80MHz) 6785MHz Chain C NSS-4

802.11ax (80MHz) 6785MHz Chain D NSS-4





802.11ax (80MHz) 6865MHz Chain A NSS-4

802.11ax (80MHz) 6865MHz Chain B NSS-4





802.11ax (80MHz) 6865MHz Chain C NSS-4

802.11ax (80MHz) 6865MHz Chain D NSS-4











802.11ax (80MHz) 6945MHz Chain A NSS-4



802.11ax (80MHz) 6945MHz Chain B NSS-4



802.11ax (80MHz) 6945MHz Chain C NSS-4



802.11ax (80MHz) 6945MHz Chain D NSS-4







802.11ax (160MHz) 6185MHz Chain C NSS-4

802.11ax (160MHz) 6185MHz Chain D NSS-4



802.11ax (160MHz) 6345 CH79 4Tx Chain A NSS-4

802.11ax (160MHz) 6345 CH79 4Tx Chain B NSS-4



802.11ax (160MHz) 6345 CH79 4Tx Chain C NSS-4

802.11ax (160MHz) 6345 CH79 4Tx Chain D NSS-4

