





802.11ax (40MHz) 6885MHz Chain C NSS-4

802.11ax (40MHz) 6885MHz Chain D NSS-4










802.11ax (40MHz) 6925MHz Chain A NSS-4



802.11ax (40MHz) 6925MHz Chain B NSS-4



802.11ax (40MHz) 6925MHz Chain C NSS-4



802.11ax (40MHz) 6925MHz Chain D NSS-4







802.11ax (40MHz) 7085MHz Chain C NSS-4

802.11ax (40MHz) 7085MHz Chain D NSS-4





802.11ax (80MHz) 6145MHz Chain A NSS-4

802.11ax (80MHz) 6145MHz Chain B NSS-4





802.11ax (80MHz) 6145MHz Chain C NSS-4

802.11ax (80MHz) 6145MHz Chain D NSS-4





802.11ax (80MHz) 6225MHz Chain A NSS-4

802.11ax (80MHz) 6225MHz Chain B NSS-4





802.11ax (80MHz) 6225MHz Chain C NSS-4

802.11ax (80MHz) 6225MHz Chain D NSS-4





802.11ax (80MHz) 6385MHz Chain A NSS-4

802.11ax (80MHz) 6385MHz Chain B NSS-4





802.11ax (80MHz) 6385MHz Chain C NSS-4

802.11ax (80MHz) 6385MHz Chain D NSS-4





802.11ax (80MHz) 6465MHz Chain A NSS-4

802.11ax (80MHz) 6465MHz Chain B NSS-4





802.11ax (80MHz) 6465MHz Chain C NSS-4

802.11ax (80MHz) 6465MHz Chain D NSS-4





802.11ax (80MHz) 6545MHz Chain A NSS-4

802.11ax (80MHz) 6545MHz Chain B NSS-4



802.11ax (80MHz) 6545MHz Chain C NSS-4

802.11ax (80MHz) 6545MHz Chain D NSS-4



802.11ax (80MHz) 6625MHz Chain A NSS-4

802.11ax (80MHz) 6625MHz Chain B NSS-4