


Label and location (bottom of the device)



ASUS Model :BQ16 Pro BE30000 Quad Band WIFI Router

RESET

Input: 12V 5A
Frequency: 2.4GHz/5GHz/6GHz
Router IP address: <http://www.asusrouter.com>

FCCID: MSQ-RTBE6X00
IC: 3568A-RTBE6X00
CAN ICES-003 (B)/NMB-003(B)

TUV 300 US

Indoor Use only

ASUSTek Computer Inc. 1F., No. 15, Lide Rd., Beitou Dist., Taipei City

WiFi Name:ASUS_XX_BQ16_Pro
H/W VER.:A1
PIN Code:XXXXXXXX
80PN:80IG08K0-M00200
MAC:XXXXXXXXXXXX

S/N:YMIG6XFSSSSXXX

Production Year:XXXX

WPS

Made in XXXXX

