

2.8. Test Photo

Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)

Description : Back View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit (Adapter: Leader, MU12-G120100)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit (Adapter: Leader, MU12-G120100)


Description : Back View of Conducted Emission Test Setup



4.8. Test Photo

Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)

Description : Front View of Radiated Emission Test Setup (Loop)




Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)


Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)
Description : Front View of Radiated Emission Test Setup (Bilog)




Test Mode : Mode 1: Transmit (Adapter: DVE, DSA-12G)
Description : Back View of Radiated Emission Test Setup (Horn)



Test Mode : Mode 2: Transmit (Adapter: Leader, MU12-G120100)

Description : Front View of Radiated Emission Test Setup (Loop)



Test Mode : Mode 2: Transmit (Adapter: Leader, MU12-G120100)

Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 2: Transmit (Adapter: Leader, MU12-G120100)

Description : Front View of Radiated Emission Test Setup (Bilog)

