



F.2 Test positions

Top Edge	Bottom Edge
	
Left Edge	Right Edge
	
Front Face	Back Face
	

F.3 PIFA antenna: reference test positions and general setup

Antenna Front View	Antenna Positions
 <p>The image shows the front view of a PIFA antenna. A ruler is placed above the antenna for scale, showing centimeters from 0 to 100. The antenna is a rectangular PCB with a yellow component on the left. A label on the antenna reads: "Company Name: SkyCross Electronics (Shenzhen) Co., Ltd. Shanghai Branch. Antenna Type: WIMAX / WLAN. Date: TEL: +86-21-6434 8850 EXT.101". The SkyCross logo is visible on the right side of the antenna.</p>	 <p>The diagram shows the antenna with its edges and faces labeled. The top edge is labeled "TOP EDGE", the bottom edge is "BOTTOM EDGE", the left edge is "LEFT EDGE", and the right edge is "RIGHT EDGE". The front face is labeled "FRONT FACE" and the back face is labeled "BACK FACE". The label from the front view is also present in this diagram.</p>
General Setup	
 <p>The image shows the general test setup. A laptop is connected to a test rig. The rig includes a PIFA antenna mounted on a stand, a horn antenna, and various cables. The setup is on a table with a blue mat.</p>	

F.4 Phantom liquid level during measurements

ELI phantom Body liquid SAR Dasy SPEAG MBL600-6000V6 Batch - 160630-1

