## Appendix C. Setup Photographs


## <Radiated Emission>

X Plane for LTE Band 7 for Down Antenna with Accessory

LF



HF






Y Plane for LTE Band 2 and Band 17 for Down Antenna with Accessory LF



HF



TEL: 886-3-327-3456 FAX: 886-3-328-4978




Y Plane for LTE Band 4 for Down Antenna without Accessory

LF



HF



TEL: 886-3-327-3456 FAX: 886-3-328-4978




Z Plane for LTE Band 12, Band 38 and Band 41 for Down Antenna with Accessory

LF



HF




TEL: 886-3-327-3456 FAX: 886-3-328-4978



Z Plane for LTE Band 5 and Band 26 for Down Antenna without Accessory LF



HF



TEL: 886-3-327-3456 FAX: 886-3-328-4978




Y Plane for LTE Band 5 and Band 12 and Band 17 for Up Antenna with Accessory

LF



HF



TEL: 886-3-327-3456 FAX: 886-3-328-4978




Z Plane for LTE Band 26 for Up Antenna with Accessory

LF



HF



TEL: 886-3-327-3456 FAX: 886-3-328-4978