


"#".B2.B3 ==> FOR DTMF ONLY

B1 ==> EMERGENCY RADIO ONLY
AND THE XTAL 4.19MHz MUST
CHANGE TO 4.032MHz CRYSTAL
N.U ==> NOT USE

- *1. R5 is determine by supply
VOLTAGE 12V -> 56K
7.2V/9.0V -> 150K
- *2. For CPU version HD704818
(OTP) Should connect the
PAG PCB and disconnect the
lead wire between "B"
to channel key.

For CPU HD404818F97 verison
disconnect the PAG PCB and
connet the lead wire from
"B" to channel key.



2 ECU A0548 1999/10/25
1 MODIFY FROM CRU71 SCH 1999/10/15