

SBT130 Manual

Specifications

Bluetooth specification: V2.0

Profiles supported: Headset, Handsfree

Transmission power: Class 2

Working range: Up to 10m

Talking time: Up to 7 Hours

Standby time: Over 300 hours

Dimensions: 50*14*10mm

Basic operations

Charging your headset

- Before to using the headset for the first time, the battery need to be fully charged
- The LED light turns Red while being charged, and will turns off automatically after being fully charged.
- When the headset is running out of battery, the headset will “beep” to indicate and the headset will switch off automatically when the battery is drained.

Turning on the headset

- Under OFF mode, press and hold MFB until you hear a short “beep” and the LED flashes blue, then the headset enters into STANDBY mode

Turning off the headset

- Under ON mode, press and hold MFB until you hear a short “beep” and the LED flashes red, the turns off, the headset enters into OFF mode

Pairing and Connecting

- Ensure the headset is under OFF mode, and the distance enables the headset can be found
- Press and hold MFB until the LED flashes blue shortly to PAIRING mode
- Activate the Bluetooth function on the phone, search available Bluetooth devices (please check the Bluetooth instruction of your phone)

■ Select the headset “SBT130” from the found Bluetooth list of the phone

■ Pair the headset with the phone and connect the headset to the phone automatically, if password requested during the operation, enter “0000”. If failed, please redo above operation, or delete the available Bluetooth list from the phone, pair and connect again, if failed again, restart the headset and the phone.

■ If the headset had paired with your phone but disconnected, once it turns on within workable distance, it will pair and connect to the last phone connected automatically

Answering a call

■ Press the MFB once

Ending a call

■ Press the MFB once

Rejecting a call

■ Press and hold MFB for about 2 seconds

Voice dialing

■ Under STANDBY mode, press MFB twice and say the voice tag as soon as hearing the short “beep” (this function depends on whether the phone supports voice dialing function, and if the voice tag has been recorded)

Last number redialing

■ Under STANDBY mode, press the MFB once about 2 seconds

Adjusting volume

■ Press “+” or “-” to adjust the volume, you will hear “beep” every adjustment until the volume max or mute

Sleeping mode

■ If the headset is not active for few minutes, it will being SLEEPING mode, the LED will not flashes, if any operation activates the headset, the headset awakes up and connects to the phone, then it keeps on working status.

WARNING:

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.