

## Notices

Information provided in this manual is a result of the design and development of AXCESS™ INC. products and is subject to change without notice. It applies only to current AXCESS™ INC. RFID systems.

No part of this manual may be reproduced, translated or transmitted, in any form or by any means, without the prior written consent of AXCESS™ INC.

### ***Responsibilities***

- AXCESS™ INC. declines all liability for any damage that might result from any errors or omissions in this document or from improper installation.
- AXCESS™ INC. can only guarantee the correct operation of its products if they are used with the software programs, systems, and consumables supplied or authorized in writing by AXCESS™ INC.
- AXCESS™ INC. recommends keeping the original packaging for transporting the equipment later.

### ***Registered Trademarks***

Product names mentioned herein may be trademarks and/or registered trademarks of their respective companies.

### ***Customer Service***

AXCESS™ INC. toll-free distributor support hotline is 1-800-577-6080. Representatives are available to answer your questions from 7:30 – 6:30 Central Standard Time.

### ***FCC ID XXXXX***

#### **CAUTION**

This equipment may **not** be modified or changed unless expressly approved in writing by AXCESS Inc. Any changes affecting the transmission or receiving power of any equipment (Tag, ATU, Reader, Antenna or other associated equipment) are prohibited by part 15 of FCC rules and will void any warranty expressed or implied by AXCESS Inc.

NeuroTag complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must not accept any interference received, including interference that may cause undesired operation.