

## 18. ATENNA LOCATIONS AND SEPARATION DISTANCES




Page 44 of 47

## 19. SAR TEST SETUP PHOTOS

<u>Top Position</u>
(with 10 mm Separation distance from Top of the EUT to phantom)




Bottom Position
(with 10 mm separation distance from Bottom of the EUT to phantom)




Page 45 of 47

Edge Position (TX1)
(with 10 mm separation distance from Edge of the EUT to phantom)



## SAR and Linearity Test Setup Photo Edge Position (TX2) – Worst-case

Edge Position (TX2) – Worst-case
with 10 mm separation distance from side of the EUT to phantom



Page 46 of 47

## 20. HOST DEVICE PHOTO





Bottom / Back



**END OF REPORT** 

Page 47 of 47