

Circuit Description.txt

Module uses 3.3V power ,before into the module must pass the filter capacitor.uses two kinds of crystal 32.768k and 32M.RF signal transmitted by the external filter ceramic antenna or an external antenna out;The Module has SMT attachment interface.