

Function of RF CIRCUIT BLOCK

1. Push the “SW1(ON)~SW5” key on transmitter and indicator led will be “on” on the front panel. The transmitter is under proper status.
2. Receiver will be also controlled by transmitter. The receiver indicator light will also be “on” to show the outlet of receiver with AC power output.
3. Push on the “SW1(OFF)” key on transmitter and the indicator light of receiver will be “OFF” It means there is no AC power output from the outlet of receiver.

CAUTION:

Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment.