

2.4GHz Wireless Optical Mouse

98543(TX) & (RX) USER'S MANUAL

Important Ergonomic Information

Some experts believe that using any mouse or trackball may cause serious injury to hands, wrists, arms, neck, or back. If you feel pain, numbness, or weakness in these areas, see a qualified health professional.

TO REDUCE THE RISK OF INJURY, FOLLOW THESE PRECAUTIONS:

- Take frequent breaks, get up and walk around several times every hour.
- Vary your tasks throughout the day.
- Keep your shoulders relaxed with your elbows at your side. Position your keyboard and mouse so you do not have to reach.
- Adjust your chair and keyboard so your upper arms and wrists are straight.
- Avoid resting your wrists on sharp edges.

System Requirement

- Mouse compatible with standard Microsoft OS
- 3rd button and wheel function require Win98/ ME/ 2000/ XP/ Vista
- 4th & 5th buttons of the mouse require Win2000/XP/ Vista to function, default as backward and forward while in Microsoft Windows ME/2000/XP/ Vista, or will require install additional driver as attached with this product.
- If your computer's operating system is Windows 98/ 98SE, please prepare the Windows98 or 98SE compact disk for system's request during the installation of mouse.

Before you begin

- Keep this installation guide for future reference! It contains Important Troubleshooting Information.
- Keep your old PS/2 or USB mouse as back-up devices.

Getting Started

Congratulations on your purchase of the Wireless Optical Mouse. By using the advanced RF technology a 360° operation is possible and no line-of-sight is required between the receiver and the mouse. The mouse featured with 1,600dpi high resolution will bring users the best operation accuracy and efficiency,

For travel, loss prevention and more power saving, the 98543(TX) designed store receiver(98543(RX)) in cavity on the bottom of the mouse, power will turn off automatically, and low power indicator on the top cover of the mouse will blink to indicate battery low power. With numerous user-friendly functions and the compact and ergonomic design, the RF mouse may offer users the best experience of utilization and the most convenience in traveling.

Package Contains

Your 98543(TX) Mouse package includes the following:

1. The wireless optical mouse
2. USB storable nano receiver(98543(RX))
3. User's manual
4. 2 AA alkaline batteries

Note : If any part is missing, please contact your dealer for a replacement immediately.

Precaution

The optical mouse ***can not*** work on a glass or mirror surface. Avoid operating this mouse on a glossy surface; otherwise, this mouse may not operate normally.


For consideration of saving battery power, it is strongly recommended to operate an optical mouse on a bright surface with fine texture to obtain lower power consumption of the high illumination LED. A very dark surface will cause higher power consumption.

For optimal performance, mouse should be no more than 5M away from receiver.

For a better transmission distance, avoid using this device on a metal plate or desktop because a large surface of iron, aluminum, copper and other metal will act as a shield or ground to the RF antenna of the mouse and receiver. Operating on a metal surface may shorten the transmission distance.

If your notebook computer has a metal (contains Al or Mg) case, the metal housing of the LCD panel will isolate partial radiation of the RF signal from the mouse. This could possibly result in reducing the distance of transmission when you operate the mouse right in front of the notebook and when the receiver is connected on the back of the notebook. However, the RF mouse should work properly while you are operating the mouse just beside your desktop computer.

Overview



Hardware Installation Guide (Mouse)

Battery installation:

1. Remove the battery compartment cover.
2. Install batteries with the positive (+) & negative (-) in the correct direction indicated by the battery compartment label.
3. Clip the battery cover back into place and make sure it is firmly closed.



(Caution: Do not look directly in to the optical emitter. Keep away from young children)

Connect the receiver with computer.

Plug in the USB receiver to any available USB port or hub connected to your computer.

(Windows will now detect the mouse and install the required drivers automatically).

CLICK ANY BUTTON, YOUR MOUSE IS NOW READY TO BE USED

Note: * During normal use, please make sure that the mouse is no more than 5M away from the receiver in order to have reliable connection.

Operation Guide

BATTERY LOW INDICATION

When battery becomes low, battery indicator LED on the top of the mouse will blink when moving or clicking the mouse. The mouse will continue to operate for a period of time depending on usage, but batteries should be replaced immediately.

OPERATIONS ON POWER SAVING MODE

In order to conserve battery power, the mouse is also designed in considering the trade-off between friendly usage and power consumption. Stages of power consumption include normal operation and idle.

The idle mode is entered immediately upon stopping moving mouse. The optical sensor of the mouse will reduce current consumption gradually. In idle mode, moving the mouse can bore the mouse back to work.

POWER ON/OFF: For the consideration of traveling purpose, this mouse designed store receiver in cavity on the bottom of the mouse, power will turn off automatically, saving more battery life.


BATTERY REMOVAL: There is no need to re-do the binding process when battery is removed from and re-installed to the mouse.

RECEIVER STORAGE

For travel and loss prevention, store receiver in cavity on the bottom of the mouse.


Storing receiver (98543(RX)):

To store in the mouse bottom, place USB plug end of receiver (A) then push the receiver into position (B). Receiver will now be locked into position.



Removing Receiver:

Push out to life receiver from cavity. The USB is now active and ready to be inserted into your computer's USB port.



GENERAL SPECIFICATIONS

- 5 Buttons wireless optical mouse.
- Precision optical sensor, 1600dpi resolution
- Long range/ less interference wireless connection
- Low power indicator.
- USB storable nano receiver
- Ergonomic design (universal left and right handed)
- 2 AA Alkaline batteries to operate the mouse.

Troubleshooting

Common troubleshooting steps

1. If you feel the mouse does not move smooth as usual, please check the battery indicator on the mouse. If batteries have lost their charge, replace them. Remember do not put the batteries in the wrong direction
2. Un-plug and re-plug the receiver.
3. Install fresh batteries in the mouse

4. Test the device on another USB port or computer
5. Some surfaces may “trick” the sensor, such as reflective surfaces like glass or mirrors. As a result this product will not work on glass or mirror surfaces. The sensor should perform well on all other surfaces.

Electromagnetic Characteristics (EMC)



Tested to comply with FCC standards

For home or office use

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE - Type acceptance: EN300 328 FHSS Device