

Operational description and Tune Up Procedure

1. APC value control RF output power, the default value is 550.
2. Measure RF output power at antenna switch.
3. If lower/higher than 30 dBm, increase/decrease APC value until output power is 30dBm.