


Ioli110 Block Diagram



- P01-EE Function Block
- P02-EE Mobile Station Modem A
- P03-EE Mobile Station Modem B
- P04-EE Mobile Station Modem C
- P05-EE MCP Memory
- P06-EE Camera CONN. & MicroP
- P07-EE USB CONN.
- P08-EE SIM & MicroSD CONN.
- P09-EE LCM & TP CONN.
- P10-EE FPC CONN. & ME parts
- P11-EE History
- P12-Audio_Block Diagram
- P13-Audio_Mic / Receiver / Speaker
- P14-Audio Headset
- P15-Audio_History
- P16-Power_Block Diagram
- P17-Power_Charger
- P18-Power_Main Power1
- P19-Power_Main Power2
- P20-Power_History
- P21-RF_Power Grid
- P22-RF_GSM PA SW
- P23-RF_VCTCXO & RX
- P24-RF_UMTS TX 1
- P25-RF_UMTS TX 2
- P26-RF_RTR6285 TRX
- P27-RF_GPS
- P28-RF_WLAN/BT Block Diagram
- P29-RF_BRF6300
- P30-RF_WL1251
- P31-Antenna