



1. External Photograph of EUT

Model Name: PD29110





Model Name: PD29110





**Model Name: PD29110**





**Model Name: PD29110**





**Model Name: PD29110**





**Model Name: PD29110**





Model Name: PD29110

Sample 2



Model Name: PD29110








**Model Name: PD29110**



Model Name: PD29110





**Model Name: PD29110**





**Model Name: PD29110**





2. Photograph of Accessory

Model Name: PD29110

List of Accessory:

Specification of Accessory		
AC Adapter 1	Brand Name	HTC
	Manufacturer	Emerson
	Model Name	TC U250
AC Adapter 2	Brand Name	HTC
	Manufacturer	Delta
	Model Name	TC U250
Battery 1	Brand Name	HTC
	Manufacturer	HT
	Model Name	BD29100
Battery 2	Brand Name	HTC
	Manufacturer	TWS
	Model Name	BD29100
Earphone 1	Brand Name	HTC
	Manufacturer	Cotron
	Model Name	HS G400
Earphone 2	Brand Name	HTC
	Manufacturer	Merry
	Model Name	HS G400
USB Cable 1	Brand Name	Coxoc
	Model Name	DC M410
USB Cable 2	Brand Name	Foxlink
	Model Name	DC M410
LCM-Main	Brand Name	Sharp
	Model Name	LQ043Y1DX02
LCM-2 <sup>nd</sup>	Brand Name	AUO
	Model Name	H430VL02 V4
Camera-Main	Brand Name	Liteon
	Model Name	09P1BA503
Camera-2 <sup>nd</sup>	Brand Name	PRIMAX
	Model Name	NBRB76

Remark: For accessories equipped with this EUT, please refer to the following photos.

Model Name: PD29110



Model Name: PD29110

**Adapter 1**



Model Name: PD29110





Model Name: PD29110



Model Name: PD29110

**Adapter 2**





**Model Name: PD29110**




Model Name: PD29110



Model Name: PD29110

**Battery 1**




Model Name: PD29110





Model Name: PD29110

Battery 2



Model Name: PD29110






Model Name: PD29110

Earphone 1



Model Name: PD29110

**Earphone 2**



Model Name: PD29110

**USB Cable 1**



Model Name: PD29110

**USB Cable 2**

