



1. External Photograph of EUT

Model Name: PD29130





Model Name: PD29130



Model Name: PD29130





Model Name: PD29130





2. Photograph of Accessory

Model Name: PD29130

List of Accessory:

Specification of Accessory		
AC Adapter 1	Brand Name	Emerson
	Model Name	TC U250
AC Adapter 2	Brand Name	Delta
	Model Name	TC U250
Battery 1	Brand Name	HT
	Model Name	BD29100
Battery 2	Brand Name	TWS
	Model Name	BD29100
USB Cable 1	Brand Name	Coxoc
	Model Name	DC M410
USB Cable 2	Brand Name	Foxlink
	Model Name	DC M410
Earphone 1	Brand Name	Cotron
	Model Name	HS G400
Earphone 2	Brand Name	Merry
	Model Name	HS G400
Camera 1	Brand Name	Liteon
	Model Name	09P1BA503
Camera 2	Brand Name	PRIMAX
	Model Name	NBRB76
LCM-Main	Brand Name	Sharp
	Model Name	LQ043Y1DX02
LCM-2nd	Brand Name	AUO
	Model Name	H430VL02 V4

Remark: For accessories equipped with this EUT, please refer to the following photos.

Model Name: PD29130




Model Name: PD29130

Battery 1



Model Name: PD29130

Battery 2



Model Name: PD29130

AC Adapter 1



Model Name: PD29130

AC Adapter 2

