



1. External Photograph of EUT

Model Name: PD42100





Model Name: PD42100






Model Name: PD42100





Model Name: PD42100






Model Name: PD42100





Model Name: PD42100





Model Name: PD42100





Model Name: PD42100





2. Photograph of Accessory

Model Name: PD42100

List of Accessory:


Specification of Accessory		
AC Adapter 1	Brand Name	HTC
	Manufacturer	Foxlink
	Model Name	TC P300
AC Adapter 2	Brand Name	HTC
	Manufacturer	Delta
	Model Name	TC P300
Battery 1	Brand Name	HTC
	Manufacturer	HT Energy
	Model Name	BD42100
Battery 2	Brand Name	HTC
	Manufacturer	TWS
	Model Name	BD42100
Battery 3	Brand Name	HTC
	Manufacturer	HT Energy
	Model Name	BTR6325B
Battery 4	Brand Name	HTC
	Manufacturer	TWS
	Model Name	BTR6325B
USB Cable 1	Brand Name	COXOC
	Model Name	DC M410
USB Cable 2	Brand Name	Foxlink
	Model Name	DC M410
LCM-Main	Brand Name	Sharp
	Model Name	LS038Y1LX03
LCM-2nd	Brand Name	Sony
	Model Name	ACX426AKN-7
Camera-Main	Brand Name	LiteOn
	Model Name	09P1BA510
Camera-2nd	Brand Name	Primax
	Model Name	NBRB92

Remark:

1. For accessories equipped with this EUT, please refer to the following photos.
2. Battery 1 and Battery 3 have the same circuit design, only the difference between them is model name.
3. Battery 2 and Battery 4 have the same circuit design, only the difference between them is model name.

Model Name: PD42100

Adapter 1



Model Name: PD42100



Model Name: PD42100






Model Name: PD42100

Adapter 2





Model Name: PD42100



Model Name: PD42100




Model Name: PD42100

Battery 1





Model Name: PD42100




Model Name: PD42100

Battery 2





Model Name: PD42100




Model Name: PD42100

Battery 3





Model Name: PD42100




Model Name: PD42100

Battery 4





Model Name: PD42100



Model Name: PD42100

USB Cable 1



Model Name: PD42100

USB Cable 2

