

SETUP Photo

Left head position close mode:



Cheek position



Tilted position

Right head position close mode:



Cheek position



Tilted position

Left head position slide mode:



Cheek position



Tilted position

Right head position slide mode:




Cheek position




Tilted position

Body position(GSM/PCS)




Front




Back

Body position(GPRS/EGPRS)



Front



Back