# Kobo eReader User Guide

June 2016 Rakuten Kobo Inc.

For Internal Use Only

# **Safety, Regulatory and Warranty Information**

Important safety, regulatory and warranty details about your Kobo eReader can be found on the Kobo website at www.kobo.com/userguides.

**Note:** The Declaration of Conformity may vary for different models of the Kobo eReader. The web site includes details of how to find your Kobo eReader model number.

### What's covered


- Anatomy of your Kobo eReader
- Turning your Kobo eReader on and off
- Charging your Kobo eReader
- Using the light
- Turning pages
- Connecting to the Kobo Store or syncing your Library over Wi Fi
- Adding books using a Micro SD card
- Adding books using your computer

#### Note:

 This device does not have 3G capabilities, and only supports wireless LAN networks (WLAN).

# **Anatomy of your Kobo eReader**

υ	Power slider	Turn your eReader on and off, or put it to sleep.
₽	USB port	Connect your eReader to your computer using the supplied USB cable to charge your eReader or to add books to it.



# **Turning your Kobo eReader on & off**

You can turn your eReader on and off or put it to sleep using the power button.

# To turn on your eReader:


Press the power button.

# To turn off your eReader:

Press and hold the power button until the off screen appears.


# To put your eReader to sleep:

• Press the power button briefly when your eReader is on.



# **Charging your Kobo eReader**

Your eReader can last several weeks after a full charge. If this is your first time using your eReader out of the box, it's recommended to charge your eReader for up to 3 hours before using it.



# To charge your eReader:

- 1. Turn on your computer.
- Connect your eReader to your computer using the USB cable.
  When you're finished charging, simply unplug the USB cable from your eReader.

# **Using the light**

You can read in areas with low light or even in the dark using the front light. The front light can be used for hours without affecting your eReader's battery life.

# To adjust screen light:

- 1. Go to your Home screen.
- Tap the Menu icon at the top of the screen.
  Tap Light.
  Drag the slider to adjust screen light.

### **Turning pages**

You can turn pages while you read by tapping or swiping the touch screen.

To turn pages in a book:

• Tap or swipe the sides of the page.

If you want to jump forward by more than a page or two, you can:

- Use the navigation bar to change pages or chapters.
- Use the Table of Contents to browse a list of chapters and change chapters.

### Connecting to the Kobo Store or syncing your Library over Wi Fi

Your eReader lets you use Wi Fi (wireless internet) so that you can shop for books, sync your library, and more. All you need is a wireless network in your area.

To connect to a wireless network:

- 1. Go to your Home screen.
- 2. Tap Sync.

Your eReader will look for Wi Fi networks that are in range.

- 3. Tap the name of the Wi Fi network that you'd like to connect to.
- 4. If required, enter the Wi Fi password.
- 5. Tap Join.

After you've connected to a Wi Fi connection, you'll see a Wi Fi symbol at the top right corner of the screen. This means that you're connected to Wi Fi. This icon will disappear when your eReader is trying to conserve battery. When you connect to the Kobo Store or sync your books, your eReader will automatically connect to Wi Fi.

### Adding books using your computer

You can connect your eReader to your computer and then drag and drop books to add them to your eReader library.

#### To do this you need:

- A Windows or Mac computer
- A USB cable provided with your eReader
- The books you want to add to your eReader in EPUB or PDF format

#### To add books using a Mac computer:

- 1. Connect your eReader to your computer using the provided USB cable.
- 2. Tap Connect on your eReader screen.
- 3. On your computer's desktop, double-click KOBOeReader.
- 4. Open a Finder window, and go to where you stored the EPUB or PDF files you want to transfer to your eReader.
- 5. Drag and drop the files into the eReader window.

#### To add books using a Windows computer:

- 1. Connect your eReader to your computer using the provided USB cable.
- 2. Tap Connect on your eReader screen.
- 3. When Window prompts you for an action, select 'Open folder to view files.' A window should open, showing the contents of your eReader.
- 4. In another window, go to where you stored your eBooks you want to add to your eReader.
- 5. Drag and drop your eBooks into the eReader window.

# Legal

### **Regulatory Compliance Statement**

# **Electronic Label**

Regulatory and device approval markings can be viewed on the Kobo eReader by completing these instructions:

- 1. From the Home screen, tap the Menu icon at the top of the screen.
- 2. Tap Settings.
- 3. Tap About Kobo Aura ONE.

### **EU Declaration of Conformity**

# **C€**0560

Български [Bulgarian] Rakuten Kobo Inc. декларира, че този оборудване е в съответствие със съществените изисквания и другите приложими правила на Директива 1999/5/EC.

Hrvatski [Croatian] Rakuten Kobo Inc izjavljuje da je ova oprema u skladu s bitnim zahtjevima i drugim relevantnim propisima Direktive 1999/5/EZ.

Česky [Czech] Rakuten Kobo Inc tímto prohlašuje, že tento zařízení je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Dansk [Danish] Rakuten Kobo Inc erklærer herved, at følgende udstyr overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Deutsch [German] Rakuten Kobo Inc, erklärt dieses Gerät entspricht den grundlegenden Anforderungen und den weiteren entsprechenden Vorgaben der Richtlinie 1999/5/EU.

Eesti [Estonian] Rakuten Kobo Inc deklareerib seadme vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

English Rakuten Kobo Inc declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Español [Spanish] Rakuten Kobo Inc declara que el equipo cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Ελληνική [Greek] Rakuten Kobo Inc ΔΗΛΩΝΕΙ ΟΤΙ ΕΞΟΠΛΙΣΜΟΣ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Français [French] Rakuten Kobo Inc déclare que l'appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Irish [Irish] Rakuten Kobo Inc declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Italiano [Italian] Rakuten Kobo Inc dichiara che questo apparecchio è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski [Latvian] Rakuten Kobo Inc deklarē, ka iekārta atbilst būtiskajām prasībām un citiem ar to saistītajiem noteikumiem Direktīvas 1999/5/EK.

Lietuvių [Lithuanian] Rakuten Kobo Inc deklaruoja, kad šis įranga atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Nederlands [Dutch] Rakuten Kobo Inc dat het toestel toestel in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Malti [Maltese] Rakuten Kobo Inc jiddikjara li dan prodott jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Magyar [Hungarian] Rakuten Kobo Inc nyilatkozom, hogy a berendezés megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Polski [Polish] Rakuten Kobo Inc oświadcza, że wyrobu jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Português [Portuguese] Rakuten Kobo Inc declara que este equipamento está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Româna [Romanian] Rakuten Kobo Inc declară că acest echipament este in conformitate cu cerințele esențiale și cu celelalte prevederi relevante ale Directivei 1999/5/CE.

Slovensko [Slovenian] Rakuten Kobo Inc izjavlja, da je ta opreme v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Slovensky [Slovak] Rakuten Kobo Inc týmto vyhlasuje, že zariadenia spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Suomi [Finnish] Rakuten Kobo Inc vakuuttaa täten että laitteet on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Svenska [Swedish] Rakuten Kobo Inc förklarar att denna utrustningstyp står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Note: Refer to the Declaration of Conformity (DoC) for any additional regulatory compliance information. To obtain the DoC for this device, please visit <a href="https://www.kobo.com/userguides">www.kobo.com/userguides</a>

#### **SAR Limits**

The exposure standards for wireless devices employ a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC/IC is 1.6 W/kg. The SAR limit recommended by the Council of the European Union is 2.0 W/kg. This device's maximum SAR value is well below the FCC/IC and EU limits with specific measurements shown in the below table.

Device Model	FCC/IC SAR 1g Limit (W/kg)	Highest Value (W/kg)
N709	1.6	0.44

Device Model	EU SAR 10g Limit (W/kg)	Highest Value (W/kg)
N709	2.0	1.82

#### **FCC Compliance Statement**



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device is limited to operation on permissible Part 15 frequencies, and does not have the ability to be configured by end users or professional installers to operate outside the authorized bands.

Important: Any changes or modifications to this product not authorized by Kobo could void the EMC and wireless compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

#### **IC Compliance Statement**

This device complies with RSS-247 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

#### Radiation Exposure Statement (for portable wireless device use)

This device complies with portable RF exposure limit in Canada and the USA set forth for an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body.

Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les Etats-Unis et le Canada établies pour un environnement non contrôlé.

Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

#### **Recycling Information**

WEEE - European Union Only



In accordance with the European Union's directive (2012/19/EU) on the Waste of Electrical and Electronic Equipment (WEEE), this symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Not all jurisdictions have appropriate infrastructure for electronics to be separately collected and treated. Please contact your local waste authority for how you should dispose of your device.

For further information on how you can recycle your device, please contact Kobo at: <a href="http://www.kobo.com/erecycling">http://www.kobo.com/erecycling</a>

#### **Other Safety Information**

- 1. The RF signals generated by your device can cause interference with or malfunction to medical devices such as pacemakers or hearing aids, including the potential for serious injury. If you have any concerns about using your Kobo device in proximity to any medical devices, please consult the manufacturer of the medical device in question.
- 2. Certain locations, such as health care facilities or construction sites, may be put at risk when radio frequency (RF) signals are generated, including through use of the wireless functionality on your device. If you see signs and other material requesting that two-way radios or cellular phones should be turned off, please turn off the wireless connection of your device in these areas.
- 3. This Kobo device has been tested to comply with specific absorption rate (SAR) limits. The maximum allowable level for the European Union is 2.0 W/kg and operation of this device is below that value.
- 4. Do not open or attempt to repair your device, including repair or replacement of the lithium ion battery in this device; contact Kobo Support for any repair and/or battery-related safety concerns.
- 5. It is recommended to only use Kobo adapters or chargers that are specifically designed or approved for your Kobo device. Do not use your adapter if the cord or plug is damaged.

- 6. Avoid exposing your device to fire and other direct heat, including hair dryers and microwave ovens and other appliances.
- 7. As this device contains small components that could lead to a choking hazard for small children, Kobo recommends that you do not open the device for any reason, including repair.
- 7. Avoid storing your device in temperatures lower than -10° and higher than  $60^{\circ}$  C (14° to  $140^{\circ}$  F). Operation of the device should occur in temperatures between 0° and 45° C (32° to  $113^{\circ}$  F). Dramatic changes in temperature or humidity may affect the functioning of the device due to the formation of condensation.
- 8. Do not force objects into your device ports (USB port), connections or buttons. If a connector does not easily fit, then it may not be a match for this device.
- 9. Do not operate the device when driving and do not store your device in a location that is covering an airbag location. Airbags erupt with incredible force and could cause injury or damage if your device or its accessories are in the path of the expected airbag's inflation area.
- 10. During travel on an airplane, follow all instructions provided by your flight operator. Your Kobo device wireless "Wi-Fi" on/off function available in your device settings.
- 11. Some individuals may be susceptible to seizures, blackouts, and eyestrain when operating devices with flashing lights or similar light patterns. If you have experienced any of these symptoms or you have any concerns about this issue, please consult a physician. It should be noted that this may occur even if you have not had a prior occurrence.