FCC ID: NS610609

WARNING:

BATTERY INSTALLATION: 1.OPEN BATTERY COVER AND INSERT A 9-VOLT BATTERY. 2. USE ONLY ALKALINE BATTERY TO PROTECT THE LIFE OF YOUR WALKIE 3.REPLACE BATTERY WHEN SOUND BECOMES WEAK OR DISTORTED.

E-MAC WALKIE TALKIE INSTRUCTION

HOW TO USE: 1. TURN THE ON-OFF SWITCH TO "ON" POSITION AND YOUR F-MAC

WALKIE TALKIE IS NOW READY TO OPERATE.

2. PRESS THE PUSH-TO-TALK SWITCH FOR TRANSMITTING. 3. RELEASE THE PUSH-TO-TALK SWITCH FOR RECEIVING.

4. BEST TRANSMITTING AND RECEPTION ARE OBTAINED WHEN THE

ANTENNA IS HELD IN A VERTICAL POSITION.

CAUTION: WHEN YOU ARE FINISHED USING YOUR E-MAC WALKIE TALKIE. ALWAYS TURN THE ON-OFF SWITCH TO THE OFF POSITION, YOU WILL ACHIEVE THE CLEAREST TRANSMISSION AND RECEPTION WHEN THE ANTENNA IS HELD IN A VERTICAL POSITION OPERATING PERFORMANCE MAY BE AFFECTED BY SURROUNDING BUILDINGS, STRUCTURES, AND EQUIPMENT.


COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.


THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT, SUCH MODIFICATIONS

YOUR E-MAC WALKIE TALKIE ARE MADE FROM HIGH QUALITY MATERIALS AND ARE DESIGNED TO GIVE HOURS OF FUN. TO KEEP THEM IN GOOD CONDITION, PLEASE REMEMBER THE FOLLOWING:

1. DO NOT DROP OR BANG YOUR WALKIE TALKIES ON A HARD SURFACE 2. DON'T WET CONTROLS OR CASING, AND AVOID USING TOY IN AREAS OF HIGH HUMIDITY FOR LONG PERIODS OF TIME.

3. DON'T TRY TO SEPARATE CONTROLS FROM CASING.






(1) SAFETY ANTENNA

② PUSH TO TALK SWITCH ③ ON-OFF SWITICH

OPEN BATTERY COMPARTMENTS AND SNAP IN ONE 9-VOLT BATTERY, (BATTERY NOT INCLUDED)



(4) SPEAKER MICROPHONE

AGES 5 AND UP

(5) BATTERY COVER



10609 LOS ANGELES, CA 90064 **ALL RIGHTS RESERVED** MADE IN CHINA www.manleytoyquest.com