



- | | | |
|--|---|-----------------|
| ① Mesh head | ⑤ Up/Down button | ⑨ Battery door |
| ② Handheld tube | ⑥ Power indicator | ⑩ Charging port |
| ③ Setup button | ⑦ Power ON/OFF button | ⑪ Cap |
| ④ LCD screen
(Channel / Freq. / battery energy) | ⑧ Hi/Low/Mute
(sensitivity selector) | |

■ Set up/ Installation

Power ON

1. Press power button ⑦ and hold 1 second to turn on.
2. When power is on, the power indicator lights blue.

Power OFF

Press power button ⑦ 2 seconds to turn the device off.

Channel select

1. Press and hold Setup button for 2 seconds; enter into the channel select mode.
2. When channel numbers flashes, press Up/Down to select preferred channel. To confirmed, press Setup button.

Charging mode

1. LED lights red when charging.
2. LED lights green when battery is fully charged.
3. Battery error:
LCD battery symbol lights flashes, and it caused by:
(1)The battery charge temperature is exceeded 60 °C.
(2)The duration of charging time for charger stand is exceeded seven hours.
(3)The battery is defected.

Synchronization

1. When turn on the device, it will synchronized automatically.
2. LED flashes blue and then steady when succeed.
3. Press short Setup button ③ to resynchronization.
If failed, it will return to the original channel.
4. Synchronization range in 3 meters.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

Consumer Alert

Most users do not need a license to operate this wireless microphone system. Nevertheless, operating this microphone system without a license is subject to certain restrictions: The system may not cause harmful interference; it must operate at a low power level (not in excess of 50 milliwatts); and it has no protection from interference received from any other device. Purchasers should also be aware that the FCC is currently evaluating use of wireless microphone systems, and these rules are subject to change. For more information, call the FCC at 1-888-CALL-FCC (TTY: 1-888-TELL-FCC) or visit the FCC's wireless microphone Web site at <http://www.fcc.gov/gb/wirelessmicrophones>.

※ Specifications are subject to change without prior notice.