

Pictures of RF250R

Reader in RF250R-housing with label









RF250R with antenna ANT8



RF250R with antenna ANT18



RF250R with antenna ANT30



RF250R with antenna ANT12



ANT18 (spec. Sensor connector only connectable to RF250R or RF350R)



ANT30 (spec. Sensor connector only connectable to RF250R or RF350R)



ANT30 (spec. Sensor connector only connectable to RF250R or RF350R)



ANT8 (spec. Sensor connector only connectable to RF250R or RF350R)

