






ATTACHMENT A to File No.: T35099-00


Internal Views RF620R-2:






ATTACHMENT A to File No.: T35099-00




ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00




ATTACHMENT A to File No.: T35099-00





ATTACHMENT A to File No.: T35099-00



Internal Views RF630R-2:




ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00






ATTACHMENT A to File No.: T35099-00





ATTACHMENT A to File No.: T35099-00




Internal Views RF640R:






ATTACHMENT A to File No.: T35099-00





ATTACHMENT A to File No.: T35099-00






ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00




ATTACHMENT A to File No.: T35099-00





ATTACHMENT A to File No.: T35099-00







Internal Views RF670R-2:




ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00



ATTACHMENT A to File No.: T35099-00

Power supply unit and Converter:

