

Label and Location

Label will be located in the center of the battery compartment

FCC ID: NZLESIGHT01
IC: 4112A-ESIGHT01
Model: eSight-01

