

15.247 Report

5) Please review the limit specified on page 28-30. The limit of -29 dBm doesn't make sense.

Gentex: The purpose of the -29 dBm "limit" is solely to indicate to the software to mark the peak of the emission not to indicate pass/fail. This value was chosen arbitrarily to guarantee the emission would exceed this level and mark the peak. Please let me know if you need additional clarification in the test report.