
倒退时转弯



11. when vehicle moves backward,turn the steering wheel counter-clockwise(fig.15), vehicle will turn inward left.

12. when rehide moves backward,turn thesteering wheel clockwise.(fig.15), vehicle will turn inward right.

PROPER USE AND PRECAUTIONS



Store vehicle in cool dry place and away from dired heat sources.



Do not leave vehicle in direct sunlight for long periods as damage may occur.



Never drive in a rainy weather.



Avoid collisions with hard surface.




Avoid sand, mud and salt.




Never drive on grass.

COMPONENT CHECK LIST

PLEASE SEARCH THE TRAY AND REMOVE ALL OF THE COMONENTS LISTED BELOW.



BATTERY PACK INSTALLATION IN VEHICLE AND TRANSMITTER



.