

# User Manual

LOGIC

iSWAG

UNONU

1.77 Inch 3G Wireless Fixed Phone

LOGIC FIXO 100G

iSWAG HEAT 137G

UNONU FIXO 100G

SWAGTEK

# Contents

<b>Basic Information.....</b>	<b>3</b>
<i>Brief Introduction .....</i>	<i>3</i>
<i>Safety Notice .....</i>	<i>3</i>
<i>Cleaning and Maintaining.....</i>	<i>3</i>
<b>Before Using.....</b>	<b>3</b>
<i>SIM .....</i>	<i>4</i>
<i>Phone Unlock .....</i>	<i>4</i>
<i>SIM Unlock.....</i>	<i>4</i>
<b>Function menu Introduction .....</b>	<b>4</b>
<i>Phonebook.....</i>	<i>4</i>
<i>Call center .....</i>	<i>5</i>
Calendar .....	7
Alarm.....	7
Torch .....	8
<i>Multimedia.....</i>	<i>8</i>
Video player .....	8
Audio player .....	8
Sound recorder .....	8
<i>Messaging.....</i>	<i>8</i>
Write message .....	8
Inbox.....	8
Drafts.....	9
Outbox.....	9
Sent messages.....	9
SMS settings.....	9
<i>File manager .....</i>	<i>9</i>
<i>Profiles .....</i>	<i>10</i>
<i>Extras.....</i>	<i>10</i>
<i>Settings .....</i>	<i>10</i>
Phone settings.....	11

Security settings .....	11
Network settings.....	12
Restore settings.....	12
<i>Shortcuts</i> .....	12
<b>Emergency call</b> .....	<b>12</b>
<b>FCC Warning:</b> .....	<b>12</b>

## **Basic Information**

---

### **Brief Introduction**

---

Thank you for choosing **1.77 Inch 3G Wireless Fixed Phone** mobile phone. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

supports two SIM cards function. In addition to basic call functions, but also to provide you with phone book, personalized ring tones, alarm, camera, image viewer, video player, audio player, One Memory Card (T-Flash card), calculator, calendar etc. A variety of practical features to facilitate your work and leisure activities, in addition, interface with personalized mobile phone design, its perfect functionality to meet your needs.

Our Company reserves without any prior notice the contents of this manual under the right to make changes.

### **Safety Notice**

---

If your phone is lost or stolen, immediately notify the telecommunications sector, or its outlet, to disable the SIM. This will allow you to take phone calls from other economic loss arising. To make you more secure use of mobile phones, please take precautionary measures, such as:

- Set up mobile phone SIM card PIN password, PIN password to prevent your SIM is unauthorized use by others.

### **Cleaning and Maintaining**

---

Do not use the bathroom where high humidity, cell phone, battery and charger, the same should also avoid the rain. Use a soft, dry cloth to clean the phone, battery and charger. Dirt outlet will lead to poor contact, power-down, which does not charge, regular cleaning.

### **Before Using**

---

---

## SIM

---

Before using your phone you must insert a valid SIM (Subscriber Identity Module) card. SIM card provide by the network provider.

**Warning:** Be sure to remove the SIM phone off before. There is absolutely prohibited in the case of an external power supply connected to insert or remove the SIM, or SIM card and mobile phone may be damaged.

---

## Phone Unlock

---

In order to prevent illegal use, your phone can set the phone lock password protected. Use this function,you must enter the phone lock password so that you can unlock the phone into the normal use state.

Enter the phone lock password, press the LSK to confirm. For example, if the phone lock password is set to 1234, then the following input: 0000.

---

## SIM Unlock

---

In order to prevent illegal use of your SIM with PIN (Personal Identification Number) password encryption protection. Use this function, if you have set the PIN password protection, every time you must enter the PIN password at boot time, so that you can unlock the SIM card and phone to normal use. Enter the PIN password, press the LSK to confirm. For example, if the PIN is set to 1234, then the following input: 1234.If there consecutive incorrect, your SIM will be network locked, the phone will ask for PUK password.

---

## Function menu Introduction

---

---

### Phonebook

---

You can use the phonebook to store records, can store the following: name and phone number.In the phonebook list, select a record, to make a call when you press the dial keys.Select a record in the phonebook, you can do the following:

- View** View the contact details or edit record.
- Send text message** Send text message to this number.
- Call** Make a call to the number.
- Edit** Can edit and save record.

- 
- Delete** Delete the record.
  - Copy** Copy the current record to Phone/SIM.
  - Add to voice Blacklist** Add the number to call blacklist number.
  - Phonebook settings:**
    - Preferred storage** Select SIM1, SIM2, Phone and All to switch, and phonebook list will change accordingly, such as select SIM1, the phonebook list will only show SIM1 records .
    - Speed dial** Open speed dial. If you long press number keys on the dialing interface, you can call up.
    - Extra numbers** You can set fixed dialing numbers.
    - Memory status** View the usage and total Phonebook capacity information.
    - Copy contacts** You can copy contacts from SIM to phone/SIM and from phone to SIM.
    - Move contacts** You can move contacts from SIM to phone/SIM and from phone to SIM.
    - Delete all contacts** You can delete all contacts of SIM card and phone.

## Call center

---

### Call history

#### Missed calls

---

Enter the missed calls menu, will display the missed calls list. Select missed call records, press the Options key:

- **View** View the details.
- **Call** Call the record number.
- **Send text message** Send text message to record number.
- **Save to Phonebook** Save the number to the phone or SIM card.
- **Add to Blacklist** Save the number to call blacklist number.
- **Delete** Delete the number.

#### Dialled calls

---

Enter the dialled calls menu to display the current record of outgoing phone list of phone numbers. Please refer to missed calls for details.

---

## Received calls

---

Enter the received calls menu to display the current record has been received mobile phone number list. Please refer to missed calls for details.

## All calls

---

Enter the all call menu, will display the all calls list. Please refer to missed calls for details.

## Delete call logs

---

Press the LSK to select "OK" to enter sub-menu to delete call records.

## Call timers

---

See SIM 1 and SIM 2 call timers.

## Call settings

## Call waiting

---

Open this feature, during the call if the new call, the network will notify you. Specific use with your network provider.

- **Activate**            launch the function.
- **Deactivate**        Close the function.
- **Query status**      Query the function's status.

## Call divert

---

Network Call Transfer service allows you to call a business case in a default transferred to a phone number you specify. The features include: Divert all voice calls, Divert if unreachable, Divert if no answer, Divert if busy, Divert all data calls.

## Call barring

---

Into the "Call barring" sub-menu, you can set the following call barring any combination to improve security. Some network providers may not provide this service call restrictions, specific use, please contact your network provider. Network provider will provide a four password so that

---

you can enable call restrictions.

Change the password to enter the old call barring password, set new restrictions on the password.

### **Line switching**

---

You can select Line1 or Line2.

### **Advanced settings**

---

#### **Blacklist:**

1. Reject numbers in blacklist: You can select on or off.
2. Blacklist numbers: You can add blacklist numbers.

#### **Auto redial:**

Through on / off settings, to activate or disable the feature. Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

#### **Call time reminder:**

**Off** Close the function.

**Single** Enter any numbers between 1-3000 (sec) , remind one time.

**Periodic** Enter any number between 30-60 (sec) , from the input time (in seconds), remind for periodic.

#### **Call Limit:**

Automaticly end the call in setting times .

#### **Answer mode:**

Any key: You can press any key to answer incoming call

Auto answer when headset mode: Incoming call could be auto answered when headset mode.

### **Calendar**

---

Enter calendar the screen will show a calendar month with the current date marked. Press the up, down, left, and right navigation keys to change the date, calendar information on the screen will be updated accordingly. Press the left soft key "Options" option to display the calendar menu.

### **Alarm**

---

Select and edit an alarm clock: You can set the setting of alarm on / off,



---

Time, Repeat and Alarm tone. You can choose to set to repeat: Once, Everyday, Custom.

## **Torch**

---

Select the on or off state to turn on/off the torch light.

## **Multimedia**

---

### **Video player**

---

Choose video player sub-menu, you can easily view the saved video player in the video list, press the LSK to enter "Options" to select the video files to do the play, rename and delete etc .

### **Audio player**

---

You can play local music in the memory card/phone memory.

### **Sound recorder**

---

In the sound recorder interface press “option”, it shows the items of record.

**New record** Start a new record. If you press stop, you can save it . If you press pause and continue to record.

**List** Display the sound that you recorded and saved.

**Settings** You can set the storage and audio quality.

## **Messaging**

---

Make sure that the information in writing before the message center number is set correctly. Access to an information menu, you can edit the SMS message.

### **Write message**

---

Edit SMS message contents.

### **Inbox**

---

Messages which are received.

---

## Drafts

---

Draft messages.

## Outbox

---

SMS are not sent successfully.

## Sent messages

---

SMS are sent successfully.

## SMS settings

---

**SIM1\SIM2** This menu can set SMSC address、 delivery report、 reply path and voicemail server function.

**Memory status:** View the SIM and Phone capacity information.

**Text msg. counter:** Received message and sent message counter of SIM1/SIM2.

**Save sent message:** You can set it on or off.

**Preferred storage:** Can set preferred storage as SIM or phone.

## File manager

---

Into the File manager menu, the menu display **Phone** and **Memory card**. Root directory, select "**Phone**", press the **LSK** to enter "**Options**" can be as follows:

- **Open** Open the root directory lists the directories and files.

- **Format** Format the memory card, this action will remove all current flash memory data.

Root directory, select "**Memory Card**", press the **LSK** to enter "**Options**" can be as follows:

-**Open** Open the root directory lists the directories and files.

-**Format** Format the memory card, this action will remove all current flash memory data.

-**Details** more information you can view, such as Name, Total size, free size.

You can play the music or video files, view Photo, copy/move/delete files, rename files and so on.

---

## Profiles

---

Profiles including General, Silent, Meeting, Outdoor and Headset. First, based on the current scene, select a different profile, then you only need a personal profile can be set and activated.

**General:** General environment.

**Silent:** For Silent environment.

**Meeting:** Vibrate mode.

**Outdoor:** For outdoor activities, need to pre-set (for example, ring volume can be set to a higher state).

Press the left soft key "Options":

**Activate:** Enable the selected profile.

**Customize:**

**Alert type:** Ring only/Vib. Only/Vib. and ring/Vib. then ring.

**Ring type:** You can choose repeat and beep once.

**Ringtone** According to their own preferences set ringtones, can also be set from the memory card custom ringtones

**Ringtone volume** In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into seven.

**Message** According to their own preferences set ringtones.

**Message volume** In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into seven.

**Keypad** You can set keypad as silent,click and tone

**Keypad volume** You can set keypad volume.

**Power on** You can set power on ringtone.

**Power off** You can set power off ringtone.

**System alert:** Set it on or off.

---

## Extras

---

### Calculator

Your phone provides you with the basic arithmetic operations. Press the left soft key "Clear", Press the right softkey "Back" to exit the calculator.

---

## Settings

---

---

## **Phone settings**

---

Into the phone settings sub-menu, you can make the following settings:

### **Time and Date**

---

In this menu, you can change the phone time and date settings.

### **Language**

---

Phone supports many kinds of language for you to select. Set the current language type, then menu and interface refresh for the corresponding language.

### **Pref. input method**

---

The phone supports many kinds of methods, to choose an input method as the default when the initial input.

### **Display**

---

**Wallpaper:** Set wallpaper.

**Screen auto lock:** Set screen auto lock time.

**Power on display:** You can set power on display.

**Power off display:** Set screen auto lock time.

**Show date and time:** You can set On/off.

### **Dedicated keys**

---

Set up,down,left and right key for shortcuts.

### **Flight mode**

---

Switch between normal mode and flight mode.

### **Misc. settings**

---

#### **LCD backlight**

You can set brightness and time.

### **Security settings**

---

Into the "Security Settings" menu, you can set the phone's security

---

options, mobile phone or SIM card to avoid unauthorized use.

### **SIM security**

---

**PIN lock:** You can set PIN lock on or off by inputting SIM PIN. And you can change PIN and PIN2.

### **Phone security**

---

**Phone lock:** You can set it on/off.

#### **Change password:**

Change the phone password, enter the old password and then enter a new password. Phone default password is 0000.

### **Network settings**

---

#### **SIM:**

Network selection(Automatic/Manual)

### **Restore settings**

---

In this menu, enter the password, once determined, the phone automatically reboot the phone after the relevant parameters can be set to return to default settings. The default password is 0000.

### **Shortcuts**

---

Shortcuts interface, Press LSK key into option, you can add,edit,delete, delete all and change order.

#### **Emergency call**

If any emergency arises, dial 112/911 (or other emergency call number) for emergency help.

Due to the nature of cellular networking, the success of emergency call is not guaranteed.

#### **FCC Warning:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any

---

interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types LOGIC FIXO 100G, iSWAG HEAT 137G, UNONU FIXO 100G (FCC ID: O55203717) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory are 0.80 W/kg, 1.17 W/kg respectively. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the

---

handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.