


< FM transmit operation description >

- Device : BH1415FV(Manufacturer : ROHM)
- Transmit antenna : internal loop antenna
- Operation set up

- Press the set up key : RCU and right side key of Car dock “”
- Select to “Device settings” by RCU(or car dock key)
- Find to “FM transmit OFF” and press “OK” key, this is logo of Sirius. If you find to “FM transmit ON”, the device is ready for transmit. And this menu is toggle(ON<->OFF) by press “OK” key.
- Select to “FM Frequencies” and frequency