

Agency label and location



The agency label is located inside the battery compartment.

