

OPERATION:

1. Place steady your transmitter then turn it on
2. A ballistic Circuit board will trigger off RF signal once you move transmitter
3. You can hear Be Be sounds from receiver when receiver gets transmitter signal.