

TX-SL010 User Manual

OPERATION:

1. Turn on the power of the remote. The power switch is at the left side of remote, please refer to Fig. 1.
2. Press lamp on/off button once, the lamp will turn on steadily. At this time, you can adjust the direction of the light beam by pressing the direction button.
3. To turn off the lamp, just press on/off once again.
4. When the light turn on, you can control the brightness of the light by pressing the button up / down.




Fig.1.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. □

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two □ conditions: (1) this device may not cause harmful interference, and (2) this device must accept any □ interference received, including interference that may cause undesired operation.