




## SMA connectors

The SMA connectors pictured in the photographs of the connected measurement setup were used **only** to connect directly to the antenna connections on the PWB.

The connector was soldered to the PWB and a cable was fitted to the PWB and HP 8595EM analyzer to take direct connected measurements.

Cable loss was taken and added to the formula for correct measurement data.



This addresses item #6 of your correspondence #8572  
(Radiated measurements were also taken)