



RS232

PWR  
RUN

ANTENNA PORTS  
PORT 1  
PORT 2  
PORT 3  
PORT 4

P2  
P3  
P4  
LOW BAND

P5  
P6  
P7  
P8  
HIGH BAND

AC POWER INPUT  
115/230 V AC

T.2A 250V AC

CAUTION  
FOR CONTINUED PROTECTION AGAINST  
RISK OF FIRE, REPLACE ONLY WITH  
THE SAME TYPE AND RATINGS  
OF FUSES AS SPECIFIED

WARNING  
DISCONNECT BOTH AC AND DC  
POWER SOURCES BEFORE SERVICING

DC-DC

1.8A  
250V  
AC



