

ANT

050-428T01-A007

FF

L3

FB

L

4L

2L

T1

STOP

050.428T01.A007

L4

NG HONSING HO

L2

27005
KD D

A R

J1

J3

J2

D1

B+

D2

C5


S1

S2

BACK

Z1

B-



050-428101-A007

Component labels on the PCB:
R1, R2, R3, R4, R5, R6, R7, R8, R9, R10, R11, R12, R13, R14, R15
C1, C2, C3, C4, C5, C6, C7, C8, C9, C10
Q1, Q2, Q3, Q4, Q5, Q6, Q7, Q8, Q9, Q10, Q11, Q12, Q13, Q14, Q15
U1, U2, U3, U4, U5, U6, U7, U8, U9, U10, U11, U12, U13, U14, U15