Atta: HENRY LEUNG

SIMPLE ELECTRONICS COMPANY

森寶電子公司

UNIT 2,7/F, HOPEFUL FACTORY CENTRE, 10 WO SHING STREET, FOTAN, SHATIN. 新界火炭禾盛街10號海輝工業中心7樓2室

TEL:(852) 27762803,26025087 FAX:(852)27762101

49MHZ

TECHNICAL DATA

A TX SECTION

DC POWER SUPPLY 1 DC IDLE CURRENT 2 DC OPERATING 3 TRANSMITTED OUTPUT FREQUENCY 4 TRANSMITTED OUTPUT POWER 5 TRANSMITTED DISTANCE 6 MODULATION AUDIO FREQUENCY 7 MODULATION SYSTEM 8 MANUAL POWER OFF

MODEL NO: 1929

MODEL NAME: RACE MASTER

DATE: 176/99

4.5V DC 3X1.5V AG13 0 MA DC (TYPICAL) 20.00 MA DC (TYPICAL) 49.860 MHZ (+/-2KHZ) LESS THAN 10MV PER METER WITHIN 50 FT IN OPEN AREA CONTROLLED BY TX_U1 IC 100% (AM)

WHEN CONTROL BAR IS RELEASED AND CONTROL KNOBA ARE NO PRESSED

B RX SECTION

1 DC POWER SUPPLY 2 DC IDLE CURRENT 3 MAX DC OPERATING HOUR **4 BATTERY OPERATING HOUR**

5 RF RECEIVING FREQUENCY 6 MANU POWER OFF

6.0V DC 4X1.5V AAA 15.0 MA DC (TYPICAL) 2.5A DC (TYPICAL) 45 MIN TYPICAL (ALKALINE TYPE) 49.860 MHZ (+/-2KHZ)

YES

FUNCTIONS

- 1 WHEN THERE IS NO TRANSMISSIONM, THE RX UNIT STOPS
- 2 WHEN FORWARD/BACKWARD BAR IS PUSHED UPWARD, THE RX UNIT WILL GO FORWARD WITH FOUR SPEEDS
- 3 WHEN FORWARD/BACKWARD BAR IS PUSHED DOWNWARD, THE RX UNIT WILL GO **BACKWARD WITH THREE SPEEDS**
- 4 WHEN THE FORWARD/BACKWARE BAR IS RELEASED, THE RX UNIT STOP AND TURN ON THE BREAK LIGHTS FEW SECOND WITH BREAK SOUND
- 5 WHEN THE STEERING WHEEL IS TURNED LEFT/RIGHT, THE RS UNIT WILL TURN LEFT/RIGHT
- 6 WHEN LIGHT BUTTON ARE PRESSED, THE RX UNIT WILL TURN ON THE FRONT LIGHTS
- 7 WHEN HORN BUTTON ARE PRESSED, THE RX UNIT WILL GENERATE HORN TWO HORN SOUND

