



注: 机身颜色图片供参考



E款注塑黑色提手
Handle "E" in Black

机背合页用T款光亮电镀色
Hinge "T" in Shiny Chrome finish

机前上下盖开关门扣用N款光亮电镀银色
Buckle "N" in Shiny Chrome finish



黑色PVC皮, 红色绒布
Black with Red Felt