

Important Safety Instructions

- Read these Instructions.
- Keep these Instructions.
- Heed all Warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding - type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **WARNING:** Shock hazard - Do Not Open.

FCC WARNINGS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna. FCC ID:OKUCAB3C382



WARNING : This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. **This product meets and complies with all Federal regulations.**

Overview





Wireless/Fast Charging

Note : Use only included AC/DC power adapter. Unauthorized power adapters may cause damage or the wireless charger may malfunction.


Wireless/Fast charging is only compatible with supported devices and the included AC/DC power adapter.

On supported devices, if the "wireless charging" or "fast/rapid charging" feature is not active, you may need to enable it from your device's Settings, Power, or Battery menu. Consult the user manual for your specific device.

Charge mobile devices with the charging pad or with the USB Charging Port on the rear of the unit.




USB Charging Port Output is 1A only.




Power & Charging

Plug the AC power cord into a standard power outlet.



Requires 2 AAA, 1.5V batteries (not included).



Bluetooth Wireless

Pairing to a Bluetooth Device and Playing Audio

After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device. If your device should become unpaired or if any pairing issues should occur, remove the unit from your Bluetooth settings and follow these steps again.

1. Press the **Source** button to switch to **Bluetooth mode**. Press and hold the **Pair** button, the **BT** symbol on the display will begin flashing and a voice prompt will sound from the speaker. *When pairing, remain within 3 feet of the unit.*
2. Using the controls on your Bluetooth device, select **ICQ988** from your Bluetooth settings to pair. When successfully paired, the **BT** symbol on the display will turn solid and a voice prompt will sound. *You can refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.*
3. Audio played through the connected Bluetooth device should now be heard through the speakers. Use the controls on the connected Bluetooth device to select and begin playing audio. Play, pause or skip audio using the controls on the device or the unit.

Clock

Setting the Clock

1. With the unit OFF, press and hold the **Clock** button until the hour begins flashing.
2. Press the **Volume +/-** buttons to adjust the hour. *Note the AM/PM indicators on the display.*
3. Press the **Clock** button to proceed.
4. Press the **Volume +/-** buttons to adjust the minute.
5. Press the **Clock** button to finish setting the time.

Alarm & Sleep Timer

Setting the Alarm

1. With the unit OFF, press and hold the **Alarm 1** button until the Hour begins flashing.
2. Press the **Volume +/-** buttons to adjust the hour. *Note the AM/PM indicators on the display.*
3. Press the **Alarm 1** button.
4. Press the **Volume +/-** buttons to adjust the minute.
5. Press the **Alarm 1** button.
6. Press the **Volume +/-** buttons to set the alarm for Radio or Buzzer.
7. Press the **Alarm 1** button.
8. Press the **Volume +/-** buttons to set the volume level for the alarm.
9. Press the **Alarm 1** button to finish setting the alarm time. Once the set alarm time is reached, the alarm will sound.
10. **To set Alarm 2, follow the above steps using the Alarm 2 button.**

Snooze and Alarm Reset

After the alarm sounds:

- Press the **Snooze** button to delay the alarm for several minutes.
OR
Press the **Power** button to turn the alarm off until the set alarm time is reached again.

Disabling the Alarm

Press the **Alarm 1** or **Alarm 2** buttons to turn the alarm ON or OFF. Note the indicator in the display.

Setting the Sleep Timer

1. Press the **Sleep** button to set the sleep timer (90, 80, 70, 60... min or OFF).
2. Once the set sleep time has expired the clock radio will automatically power off.

FM Radio

Tuning the FM Radio

1. Press the **Power** button to turn the unit on.
2. Press the **Source** button to switch to **Radio mode**, then press the **Tuning +/-** buttons to select the desired frequency, or press and hold to quickly scan the frequencies.


Saving Radio Presets

1. Press Scan to automatically scan and set radio presets.
2. To manually set a preset, tune to the desired frequency (see above steps).
3. Press and hold the **Prog** button. The display will begin flashing a preset. Ex: "P01".
4. Press the **Tuning +/-** buttons to select the preset to be saved. (P01 to P20).
5. Press the **Prog** button to save that preset.
6. To cycle through presets, press the **Prog** button, then the **Tuning +/-** buttons to select.

Aux In

Requires a 3.5mm audio cable (not included).

1. With the unit powered ON, connect a 3.5mm audio cable to the **Aux In** on the rear of the unit and the **audio output** on an audio device.
2. Press the **Source** button to select Aux-In Mode. Use the controls on the connected device to play your audio through the unit.



International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iliveelectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iliveelectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iliveelectronics.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iliveelectronics.com

Customer Service: 1-888-999-4215 | **Email Support:** prodinfo@dpiinc.com | **Email Parts:** partsinfo@dpiinc.com

Copyright © 2018 Digital Products International (DPI, Inc.). All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

