

# Functional Description: T60TX-0xSOL Version A1

# 1 Introduction

The transmitter units T60TX-01,2,3,4,6SOL are aimed for remote control applications.

# 2 Conceptual specification

#### 2.1 Number of functions

1,2,3,4 or 6 functions. Each one is activated by pushing down one of the 6 push buttons. All 6 functions can be used simultaneously.

#### 2.2 Code

#### 2.2.1. Number of codes

#### System 460

8 position tri-state switch (6.561 codes).

# System T60

10 position tri-state switch (59.049 codes) and a unique private ID-code for each transmitter (16.777.216 ID-codes)

## 2.2.2. Code setting

## **SYSTEM 460 COMPATIBILITY**

Select an individual code on trinaryswitch 1-8.

## SYSTEM T60

Select an individual code on trinaryswitch 1-10.

The unique private ID-code is programmed by default in the transmitter and cannot be changed.

# 3 Functionality

When one or several buttons is pushed down the transmitter starts up and transmits a signal to the receiver to activate the relay(s), according to which button(s) that were pressed down.

# 4 Document history

Issue	Date	Author	Comments	Approved by:
A1	2002-11-29	R. Petersson	First issue	