

Installing the Remote ODU

Indoor use

The remote ODU can be mounted indoors with the antenna aimed through a window. The glass will attenuate the signal. The amount of attenuation depends on the type of glass.

- Double pane glass, uncoated: 10dB
- Low emission glass: 20dB

The range of the remote unit is reduced when used indoors. If the office glass is low emission glass, the reduction in range may be significant.

Inspect and verify the equipment:

- 1 Verify that the equipment and hardware matches the packing list.
- 2 Inspect the equipment for shipping damage.

Install the Remote ODU

- 1 Place a U-bolt around the pole through holes in the ODU assembly.
- 2 Place flat washers on the U-bolt.
- 3 Loosely tighten nuts on the U-bolt.
- 4 Repeat with the other U-bolt.

Warning



You are required to keep a minimum of 20cm from the antenna when power is applied to the system. This complies with the FCC limits for radio frequency exposure.
