






autec		
MODEL: RNF	TYPE: LA00M	
RADIO MODULE	AIRRT32NM	FREQUENCY 915-928MHz
POWER SUPPLY	12-24V = / 24V ~ (1A)	FCC ID: OQA-RNFLA00M
FREQUENCY	433.050-434.790MHz	IC: 9061A-RNFLA00M





This radio device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.

 - Before switching on please read the user manual. - Adhere to safety rules.
 - Disconnect power source and wait 10 seconds before opening.
 - Prima dell'accensione leggere il manuale d'uso. - Attenersi alle norme di sicurezza. - Togliere l'alimentazione e attendere 10 secondi in caso di apertura.

TAT278.01

RNF label



RNF label position