

Floated Camping Lantern (with Remote Control)



Model No: SU-811R, RU-811R, CU-811R



Function:

Waterproof / Floating.

Using the Remote Control, just hold the button for less than 0.5 second to turn on the light and turn it off for holding over 1.5 second.

When the power of the batteries in the Remote Lantern is less than 4V, new batteries must be changed otherwise the Remote Control cannot be used.

To make the U-Tube more durable, each time for using the light, it is better to turn it on after 20~30 seconds.

Floated Camping Lantern (with Remote Control)

STRUCTURE DIAGRAM

