

NO.: 84470

5M

RC Transmitter x 1

NGE

RC Vehicle x 1



FUNCTION



# Contents

-RC Vehicle (Vehicle) x 1

-RC Transmitter (Transmitter) x 1

-USB Cable Adaptor x1

-Instruction Manual x 1


### **Battery Precaution**


- The 3.7V rechargeable battery pack must be charged before use by utilizing the USB 1. Cable Adaptor which included.
- Do not overcharge the battery pack. Do not charge for more than 4 hours. 2
- 3. Do not charge the battery pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.
- 4. Do not cover the battery pack with any sort of materials while charging.
- Do not touch the battery pack when it is hot. Wait until the battery pack cools before 5. installing it in the Vehicle and before recharging.
- 6. Do not dispose of the battery infire.
- Do not dismantle the battery or charger, and do not cut the battery or charger cables. 7.
- 8. The battery pack will be warm after charging, and hot after use in a vehicle.
- 9. The supply terminals are not to be short-circuited.
- 10. Rechargeable batteries are only to be charged by adults.
- 11. Battery replacement must be only made by adults.
- 12. The USB Cable Adaptor is not atoy.
- Charge only type (150mAh Max.) rechargeable battery packs. Other types of 13. batteries may burst causing injury to persons and damage. This power unit is

**Battery Installation** 

# For Transmitter (Fig. 1 and Fig. 2)


- 1. Unscrew the screw on the battery cover
- Open the battery cover 2
- Install 2 new 1.5V "AAA" batteries with correct polarities (+/-) 3 as shown inside the battery compartment
- Close the battery cover
- Tighten the screw on the battery cover 5.





## Charging the Rechargeable Battery Pack for the Vehicle (Fig. 3)

- 1. Connect the 3.7V rechargeable battery pack to the USB Cable Adaptor.
- Recommend use Computer connect USB cable adaptor to charge th battery. 2. If use adaptor connect USB Cable Adaptor to charger battery,
- the output limit cannot exceed 3.7V.
- The charging time for a full charge is about 1 hour. Full charge battery usage Max. 30 mins.
- 4. When charging is completed, unplug the USB Cable Adaptor.
- 5. Disconnect the rechargeable battery pack from the USB Cable Adapter.




3.

# 

- Be Sure To Charge Battery Pack Before Using.
  If Battery Pack Is Hot After Use, Allow To Cool
- Before Recharging. Do Not Dispose Of Battery Pack In Fire.
- Do Not Dispose of Dattery Pack That Shows
  Leakage Or Corrosion, Or Attempt To Open Battery Pack

USB Cable Adaptor is intended to be used for charging 3.7V rechargeable battery pack with capacity 150mAh Max. It cannot be used for charging non-rechargeable batteries. Regular examination of USB Cable Adaptor for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the charger or battery pack charge until such damage has been repaired. Note that the AAA battery is non-rechargeable and is not to be recharged. Only batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor.




- 15. Non-rechargeable batteries are not to be recharged.
- 16. Diuerent types of batteries or new and used batteries are not to be mixed.
- 17. Rechargeable batteries are to be removed from the toy before being charged.
- 18. Batteries are to be inserted with the correct polarity.
- 19. The packaging has to be kept since it contains important information.
- intended to be correctly orientated in a vertical or floor mount position. This

3.7V Lithium 150mAh or Vehicl USB Cable Adaptor

BATTERY REQUIREMENTS:

or Transmilter Included)




# **How To Bind**


- 1. Turn on the Vehicle
- 2. Hold the Signal Match Button for around 4 second then the Transmitter signal light will flash for 6-7 second.
- 3. After the wheels of the Vehicle turn left and right and the LED light of the Transmitter stops flashing, the binding process completed for playing.
- 4. If it cannot complete within 8 seconds, please turn off the Vehicle and re-start the binding process.
- 5. When the binding process is done, whenever switching the Vehicle on and off, it searches for the code that it memorized, and will only lock on to the Transmitter signal containing that code.

6

6. Please turn off the Vehicle and re-start all binding process if changing to another 2.4GHz Transmitter for playing.



Use the Steering Wheel to control the Vehicle turning left or right



- 4. Play on smooth surface to have the optimum performance 5 Remember to switch OFF the power of the Vehicle after
  - playing

Do not attempt to disassemble the Vehicle or Transmitter

Make sure the batteries are installed with correct polarities (+/-) as shown inside the

Remove the package and take out all accessories before giving the Vehicle and

The packaging and instruction manual contain important information. Please keep them

Warning! Choking Hazard. Not suitable for children under the age of 3 years due to

We reserve the right to improve/amend specifications and colors without notice.

The optimum control range is up to 15m outdoor

battery compartment

for future reference

small parts

Transmitter to child to play

#### **Performance Tips**

- Do not drive on grass, dirt, sand, dusts, carpet or go through water. Do not drive in windy or rainy weather. Avoid direct impact the Vehicle with obstacles.
- 2
- Switch OFF the power when not in use to prevent damage of Vehicle and Transmitter due to leakage of electrolyte from batteries. 4 5
- Remove all batteries from the Vehicle and Transmitter when not in use for long period. Keep fingers, hair and loose clothing away from wheels.
- The operating range can be affected by a variety of factors a) Low Voltage of batteries in Transmitter or Vehicle
- b) Interference from other items that emit radio frequency signals Outdoor usage is recommended in order to get optimum control range.
- Recommend to play the vehicle on a clean and smooth surface.
- 10. Clean the battery compartment to make sure it is free from dust to prevent poor contact of batteries

#### FCC label compliance statement:

- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
- 1. This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with 2 the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **RSS-210 Compliance Statement:**


This device complies contains licence-exempt transmitter that comply with Innovation Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### **Declaration of Conformity**

The product is in conformity with the requirement of EU Directive 2014/53/EU.

#### **Environmental notes:**



- You can return it at collection points for the recycling of electronic and electronical instruments The symbol on the item, instruction manual, hangtag or packing is showing this clearly.



Materials should be recycled according to their respective markings. Recycling of old devices or other re-use of materials contained therein represents an important contribution to environmental protection.

Please ask at your local community for the correct collection point.

## **Disposal of batteries**

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries

at public collection points in your area or wherever batteries are sold. You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:



Pb=Battery contains lead Cd=Battery contains cadmium Hg=Battery contains mercury

Frequency band: 2410-2475 MHz Maximum radio frequency power transmitted: <0dBm



KIDZTECH TOYS MANUFACTURING LTD. Room 802, 8/F., Inter-Continental Plaza, 94 Granville Road, TST East, Hong Kong. Tel: (852) 27218868 info@kidztech.net Made in China http://www.kidztech.net





Conforms to the safety requirements of ASTM F963



Cautions



