Conducted Emission Test Setup View

Test Setup Front View for the wireless mode.




Test Setup Back View for the wireless mode.




Test Setup Front View for the PC mode.




Test Setup Back View for the PC mode.



Radiation Emission Test View For 30MHz-1000MHz for PC mode



Radiation Emission Test View For 30MHz-1000MHz for wireless mode



Radiation Emission Test View For 1GHz-5GHz

