

3.7. Test Photo

Test Mode : Mode 1: Transmit (USB)

Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 1: Transmit (USB)

Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 2: Transmit (Car Charger)
Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 2: Transmit (Car Charger)
Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 3: Transmit (Adapter)
Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 3: Transmit (Adapter)
Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 1: Transmit

Description : Front View of Radiated Emission Test Setup (Horn)

