

TABLE OF CONTENTS**CHAPTER 1 ID LABEL/LOCATION INFO**

1.1 Rear Panel FCC Label	1-1
1.2 Rear Panel Manufacturer's Label.....	1-1
1.3 Rear view, Axcera-HU5000AD Transmitter w/FCC and Manuf. Label.....	1-2

CHAPTER 2 EXTERNAL PHOTOS

2.1 Front view, Axcera-HU5000AD Transmitter	2-1
2.2 Rear view, Axcera-HU5000AD Transmitter	2-2
2.3 Front view, External Exciter Digital Modulator	2-4
2.4 Rear view, External Exciter Digital Modulator.....	2-4
2.5 Top view, External Exciter Digital Modulator	2-4

CHAPTER 3 SCHEMATICS**CHAPTER 4 TEST REPORT**

4.1 RF Power Measurements	4-1
4.2 Modulation Characteristics.....	4-2
4.3 Error Vector Magnitude (EVM) and Signal to Noise Ratio (SNR)	4-3
4.4 Frequency Response and Group Delay	4-4
4.5 Peak to Average	4-4
4.6 Phase Noise	4-5
4.7 Occupied Bandwidth	4-6
4.8 Conducted Spurious Emissions.....	4-7
4.9 Radiated Emissions.....	4-30
4.10 Frequency Stability	4-32
4.10.1 Pilot Frequency Measurement.....	4-34
4.11 Test Equipment	4-35

CHAPTER 5 USER'S MANUAL**CHAPTER 6 INTERNAL PHOTOS**

6.1 Front view, Exciter Chassis Assembly - Empty	6-1
6.2 Side view, Exciter Upconverter Assy – Used w/ Exciter Mod. (Exciter)	6-1
6.3 Side view, Exciter Downconverter Assy – Used w/ Exciter Mod. (Exciter) ...	6-2
6.4 Side view, Control / Power Supply Assembly (Exciter)	6-2
6.5 Side view, Power Amplifier Assembly (Exciter)	6-3
6.6 Front view, Exciter chassis - Populated	6-3
6.7 Top view, External Exciter Digital Modulator	6-4
6.8 Front view, 4-Way Splitter Assembly x2 (RF Amplifier Cabinet)	6-5
6.9 Side view, Power Amplifier Assembly x8 (RF Power Amplifier Cabinet)	6-5
6.10 Rear view, 8-Way Combiner Assembly (RF Amplifier Cabinet).....	6-6
6.11 Side view, PA Power Supply Assembly x 2 (RF Amplifier Cabinet)	6-6
6.12 Front view, AC Power Supply Assembly x2 (RF Amplifier Cabinet)	6-7
6.13 Front view, Load Regulator Assembly (RF Amplifier Cabinet)	6-7

CHAPTER 7 PARTS LIST/TUNE-UP INFO

7.1 Parts List	7-1
7.2 Tune-up Information	7-1
7.2.1 System Preparation	7-1
7.2.2 Module Replacement	7-1
7.2.3 Initial Test Set Up	7-2
7.2.4 Setting Up the Output Power of the Transmitter	7-2
7.2.5 Setting Up of AGC 1	7-3
7.2.6 Setting Up of AGC 2	7-3
7.2.7 Setting Up of the Overdrive Threshold	7-4
7.2.8 Axciter Relay Samples	7-4
7.2.9 Upconverter / Downconverter Adjustment	7-4
7.2.10 System Calibration of Forward & Reflected Power	7-4
7.2.10.1 Forward Power Calibration.....	7-4
7.2.10.2 Reflected Power Calibration	7-5

CHAPTER 8 OPERATIONAL DESCRIPTION - MODEL Axcera-HU5000AD

8.1 General Description	8-1
8.2 Technical Specifications	8-1
8.3 Performance Specifications.....	8-1
8.4 System Overview	8-2
8.4.1 Axciter - External Digital Modulator.....	8-2
8.4.2 Exciter Tray.....	8-2
8.4.2.1 Axciter Upconverter – Used with Axciter Modulator	8-3
8.4.2.2 Axciter Downconverter – Used with Axciter Modulator	8-3
8.4.2.3 Control & Monitoring / Power Supply Module (Exciter)	8-4
8.4.2.4 Power Amplifier Module (External Power Amplifier)	8-4
8.4.3 RF Amplifier Cabinet Assembly	8-4
8.5 Control and Status	8-6
8.5.1 External Axciter Digital Modulator Tray.....	8-6
8.5.2 Exciter Tray.....	8-6
8.6 Input and Remote Connections.....	8-8
8.6.1 Remote Interface Connections (Axciter Modulator Tray)	8-8
8.6.2 Remote Interface Connections (Exciter Tray)	8-8
8.7 AC Input	8-9
8.7.1 External Axciter Modulator Tray	8-9
8.7.2 Exciter Tray.....	8-9
8.7.3 RF Amplifier Cabinet.....	8-9
8.8 System Operation	8-9
8.8.1 Principles of Operation.....	8-9

CHAPTER 9 CERTIFICATION OF TEST DATA

TRAK SYSTEMS MODEL 8821 DATASHEET	SHEET 1
TRAK SYSTEMS MODEL 8821 DATASHEET	SHEET 2
CRYSTEK CORP. DATASHEET	SHEET 1