


Front / Side



Back



Open



Bottom



2 screw maintain the 2 part of the reader