

APPENDIX D – DUT AND ACCESSORY PHOTOS

Figure	XL-185P Radio			
7				
	Front w/o Antenna	Back w/o Antenna	Left w/o Antenna	Right w/o Antenna
				
	Top w/o Antenna		Bottom	
				

Figure: 8

Accessory Photo

Part Number

14035-4010-04 Li_Ion Battery Pack

Front View



Back View



Figure: 9

Accessory Photo

Part Number

14035-4010-01 Li_Ion Battery Pack

Front View



Back View



Figure: 10

Accessory Photo

Part Number

12082-0600-01 Standard Speaker Microphone



Figure: 11

Accessory Photo

Part Number

14002-0197-01 Hirose to Unity Adapter



Figure: 12

Accessory Photo

Part Number

12150-1000-01 Premium Speaker MIC, Fire, NC



Figure	14035-4450-01 Antenna
13	




Figure	14035-4450-02 Antenna
14	




Figure	KRE1011223/02 Antenna
15	




Figure	14002-0218-01 Leather Belt Loop w/ 12082-3230-01 D-Swivel
16	
Front	
	
Back	
	
Side	
	

Figure	KRY 101 1609/1 Leather Belt Loop w/ 12082-3230-01 D-Swivel
17	
Front	
	
Back	
	
Side	
	

Figure	12082-1290-01 Belt Clip
18	
Front	
	