

APPENDIX D – DUT AND ACCESSORY PHOTOS






| Figure | XL-185P Radio | | | | | | |
|---|----------------------|--|--|--|--|--|--|
| 7 | | | | | | | |
| Front w/o Antenna | | Back w/o Antenna | | Left w/o Antenna | | Right w/o Antenna | |
|  | |  | |  | |  | |
| Top w/o Antenna | | | | Bottom | | | |
|  | | | |  | | | |

Figure: 8

Accessory Photo

Part Number

14035-4010-04 Li_Ion Battery Pack

Front View



Back View



Figure: 9

Accessory Photo

Part Number

14035-4010-01 Li_Ion Battery Pack

Front View



Back View



Figure: 10

Accessory Photo

Part Number

12082-0600-01 Standard Speaker Microphone



Figure: 11

Accessory Photo

Part Number

14002-0197-01 Hirose to Unity Adapter




Figure: 12

Accessory Photo



Part Number

12150-1000-01 Premium Speaker MIC, Fire, NC





| | |
|--|--|
| Figure | 14002-0218-01 Leather Belt Loop w/ 12082-3230-01 D-Swivel |
| 16 | |
| Front | |
|  | |
| Back | |
|  | |
| Side | |
|  | |

| | |
|--|---|
| Figure | KRY 101 1609/1 Leather Belt Loop w/ 12082-3230-01 D-Swivel |
| 17 | |
| Front | |
|  | |
| Back | |
|  | |
| Side | |
|  | |

| | |
|--|--------------------------------|
| Figure | 12082-1290-01 Belt Clip |
| 18 | |
| Front | |
|  | |