

## **APPENDIX D – DUT PHOTOS**

Figure D1	XL-2001	P C1D1 Radio	
Front	Back	Left	Right
w/o Antenna	w/o Antenna	w/o Antenna	w/o Antenna
Тор		Bott	om
w/o Antenna		WARNING – Explosion hazard – Batteries must only be dranged in an eek known in be onorhazard ositig koeffits SEMEXIT – Filsque d'axplosion – kind évinane iourinsque d'explosion, s'assurei que i emplacement iourinsque d'explosi	



Figure D2	XL-2001	P C1D1 Radio	
Front	Back	Left	Right
w/o Antenna	w/o Antenna	w/o Antenna	w/o Antenna
HARRES XL-200 XL-200			HARRIS O
Тор		Bot	tom
w/o Antenna			
		vino Izum zeinelleä – bissein noisolgxä – ONINSAW aviveb nitä– noisolgka baupaika – INBMGSZI PRAMA inemeseigene i aup reuzes 2. noisolgka baupair luoi einelled ei reginerda eb Ineve xueregineb non angleëb tee EEDDI Bros VIII and State and State and State and State EEDDI Bros VIII and State and State and State and State EEDDI Bros VIII and State	







## Figure: D4 **Accessory Photo** 14034-4010-01 Li\_lon Battery Pack Part Number **Front View Back View** 0



T

Figure: D5	
	Accessory Photo
Part Number	12082-0600-01 Standard Speaker Microphone
















Figure KRY 101 1609/1 Leather Belt Loop w/ 12082-3230-01 D-Swivel D10 Front Back Side



Figure	12082 1200 01 Balt Clip
D11	12082-1290-01 Belt Clip
	Front